

trangia

INSTRUCTIONS FOR PREHEATER ART.NO 602101

Preheater for TRANGIA STOVES No. 25 and 27.

The preheater has an absorbent pad which will absorb 0,5 cl spirit. The preheater is required at temperatures of 0° Celsius and below. The lower the temperature, the more time it saves.

INSTRUCTION FOR USE: Remove the preheater completely or pull it down into the lower groove. Add a few drops of spirit to the absorbent pad (more in extreme cold). Attach the preheater beneath the spiritburner. Always turn the preheater round to check that it is placed in the groove. Fill the burner as usual. Place it beside the burner opening in the windshield.

STEP 1: Ignite the holes into the preheater from the side or from beneath. Put down the burner quickly. You should preferably use a glove, grip or handle.

STEP 2: Ignite the burner as usual. The preheater will burn for about 2 minutes, giving the stove a quick start and saving up to half the time required for bringing water to boil.

WARNING! BEWARE OF DARTING FLAMES AND STRONG HEAT.

The fast burner is provided with a efficient economy ring for regulating the flame. Turn out the brown cover and place it over the burner when you want to save fuel. The economy ring is adjustable and makes an excellent extinguisher.

WARNING! MAKE SURE THAT THE BURNER HAS EXTINGUISHED AND LET IT COOL BEFORE ADDING MORE SPIRIT.

TRANGIA FAST BURNER

